

Switching Battery Banks

Quick Reference Guide

SWITCH OFF POWER LEADS AT POWER POINT OUTSIDE THE POWER BOX



SWITCH OFF THE INVERTER



SWITCH THE RED BATTERY TOGGLE
SWITCH FROM '1' TO '2'
OR
FROM '2' TO '1'
(SWITCH VIA '0' POSITION)

***WARNING - NEVER SWITCH TO POSITION '1+2'
THIS MAY CAUSE SYSTEM OVERLOAD***



SWITCH ON INVERTER



LEAVE LID AJAR TO
VENTILATE SYSTEM



SWITCH ON POWER LEADS AT POWER POINT